

**No.2
Main
Landing
Gear**

- ① Check where the brake pipe (J-24) has been glued.
- ② It is the position to align the brake pipe with the side of the tire. It is not necessary to glue these two parts together, but assemble while checking that the positions align.
- ③ When installing the tires, double check which is the left and which the right tire.
- ④ The section of the main landing gear to glue. Glue thoroughly, while also checking the installation of the inner parts of the engine nacelle.

Main Gear Covers